



FRIATOOLS® TECHNICAL EQUIPMENT

RPS REPAIR SET





Artic descrip		Dimension	Order Ref.	Stock- status	вх
Repair set		all dimensions	613701	1	1
Extensio	n set	all dimensions	613715	1	1
Repair balloo	on type 1	d 90 - d 180	613702	1	20
Repair balloo	on type 2	d 200 - d 315	613703	1	20
Repair balloo	on type 3	d 355 - d 450	613704	1	5
Repair balloo	on type 4	d 500 - d 560	613705	1	5
Repair balloo	on type 5	d 630	613706	3	5
Repair balloo	on type 6	d 710	613707	3	5
Repair balloo	on type 7	d 800	613708	3	5
Repair balloon type 8		d 900	613709	3	5
Transpor	t box		613700	1	1





FRIATOOLS® TECHNICAL EQUIPMENT RPS REPAIR SET

Application

The FRIATOOLS RPS repair kit with repair balloons functions as a reliable barrier against residual water discharging from the pipe.

The RPS repair kit keeps the work area dry while a electrofusion welding is being prepared for the repair of damaged or for the integration of new HDPE drinking water pipes.

The crucial difference

Having the correct tools to perform installation on site makes all the difference. We see ourselves as specialists in the electrofusion of HDPE piping systems, so our development work has also included equipment and accessories for your needs from the very outset.

We know exactly what matters and what is needed in the field, and we can offer you a range of equipment tailored to the daily challenges encountered on the building site:

Put your trust in tools that produce the perfect results.

Good reasons for using the FRIATOOLS repair kit RPS:

- Use of the repair ballon technique for the safe retention of residual water from pipelines.
- Suitable for repair work on damaged pipelines or for connections
- Allows a dry working area during the processing of a electrofusion fitting in the nominal diameters d 90 - d 900
- Consisting of universal repair kit with pump, manometer, driller and connecting hose as well as additional repair ballons for each nominal diameter
- Optional extension set consisting of additional connection hose and manometer
- In order to close the bore after the repair, FRIALEN repair saddles VVS (≤ d 225) or VSC-TL, SA-XL, RS-XL (≥ d 225) are required (see price list FRIALEN)