

	FRIAMAT I (1. Generation)	FRIAMAT II (2. Generation)	FRIAMAT III (3. Generation)	FRIAMAT 4 ECO (4. Generation)	FRIAMAT 4.5 (5. Generation)	FRIAMAT 6 ECO (6. Generation)	FRIAMAT 7 (7. Generation)
							
Year of manufacture	until 1999	until 2006	until 2014	until 2018	until 2020	since 2018	since 2020
Device types / Description	FRIAMAT FRIAMAT T FRIAMAT E FRIAMAT L FRIAMAT TL	FRIAMAT FRIAMAT T FRIAMAT E FRIAMAT LE FRIAMAT L FRIAMAT TL FRIAMAT E print	FRIAMAT prime FRIAMAT basic FRIAMAT memo	FRIAMAT prime eco FRIAMAT basic eco FRIAMAT basic print FRIAMAT geo print	FRIAMAT prime FRIAMAT basic	FRIAMAT prime eco FRIAMAT basic eco FRIAMAT print eco	FRIAMAT 7 prime FRIAMAT 7 basic
Tools service							
Annual maintenance in accordance with DVS 2208 part 1 or DGUV V3	✓	✓	✓	✓	✓	✓	✓
Repairs	✗ No longer possible or only possible to a very limited extent (lack of spare parts due to age of unit)	✗ No longer possible or only possible to a very limited extent (lack of spare parts due to age of unit)	⚠ Limited (lack of spare parts due to age of equipment)	✓	✓	✓	✓
Documentation and digitisation (only FRIAMAT with documentation function)							
USB interface	✗ Parallel interface only (no longer supported by MS Windows and new PC/ laptops)	✗ Parallel interface only (no longer supported by MS Windows and new PC/ laptops)	⚠ Standard USB interface (only FRIAMAT memory stick up to 2GB)	⚠ Standard USB interface (only FRIAMAT memory stick up to 2GB)	⚠ Standard USB interface (only FRIAMAT memory stick up to 2GB)	✓ Standard USB interface (commercially available USB sticks of type FAT 32 with up to 256 GB)	✓ Standard USB interface (commercially available USB sticks of type FAT 32 with up to 256 GB)
Workflow and FRIAMAT APP	✗	✗	✗	✗	✗	✓ FRIAMAT prime eco fully compatible	✓ FRIAMAT 7 prime fully compatible
Software update by customers possible	✗	✗	✗	✗	✗	✓	✓